


Cuisinart®

CARE & SAFETY INSTRUCTIONS



OEM Gourmet Heat Distribution Plate

85-2335 (G525-0015-02)

EXACT FIT FOR CUISINART® GOURMET MODELS:

85-3056 (G52501), 85-3057-6 (G52502), 85-3058-4 (G52503), 85-3059-2 (G52504),
(85-3056-8, G52505), 85-3057-6 (G52506), 85-3058-4 (G52507), 85-3059-2 (G52508),
85-3058-4 (G52509), 85-3059-2 (G52510), 85-3108-6 (G53501), 85-3109-4 (G53502),
85-3110-8 (G53503), 85-3111-6 (G53504), 85-3122-0 (G53505), 85-3123-8 (G53506),

READ AND SAVE MANUAL FOR FUTURE REFERENCE.

The Cuisinart® OEM Gourmet Heat Distribution Plate is designed and intended for use with Cuisinart® Gourmet barbecue only. This product will replace the original heat distribution plate sold with your Cuisinart® Gourmet barbecue.

CARE AND MAINTENANCE

⚠ ATTENTION

- Move barbecue to an open outdoor area prior to removing old heat distribution plates and installing your new replacement heat distribution plates.
- Ensure barbecue is cool before proceeding. Turn barbecue control knob(s) off and gas supply off.
- Lift barbecue lid to expose your barbecue's cooking surface.
- Remove your cooking grates.
- Remove your damaged heat distribution plate and replace with your **NEW** heat distribution plate.
- Ensure that your heat plates are seated directly over your burner and under your cooking grates.

Your New Cuisinart® Heat Distribution Plate will serve to

- Protect your burner system from salts, fats and other cooking contaminants that cause blockages, safety issues and pre-mature deterioration.
- Distribute heat for more even and consistent cooking temperatures.
- Eliminate the need for cooking radiants such as Lava Rock and Ceramic Briquettes.

For proper maintenance

- Always perform regular maintenance on your heat distribution plates to remove all debris. Do not allow fats, salty and acidic drippings from marinades to accumulate on your heat distribution plates.
- Allowing grease and debris to build up will cause flare-ups and potentially a grease fire.
- Using a grill brush, or plastic paint scraper remove any buildup from heat distribution plates. Clean away any remaining debris with mild soap and warm water. Dry thoroughly.

How to store your heat distribution plates

- If your barbecue is being stored outdoors you should remove, clean, and store your heat distribution plates indoors to avoid moisture and humidity damage.

Failure to do all of the above will lead to rapid deterioration of this part. Without removing all heat plates and inspecting them you may not realize the degree of deterioration caused. Following all instructions within this document will ensure a long life for this part and the best performance of your barbecue.

**For more information
please visit us online at www.cuisinartbbqs.com**

Join the conversation



facebook.com/cuisinartbbqs



twitter.com/cuisinartbbqs

Cuisinart® is a registered trademark used under license

© 2019 Trileaf Distributions Trifeuil
